



FASI / phases 1-2



SOLO PER TAVOLI CON PIANO IN CRISTALLO FOR TABLES WITH CRYSTAL TOP ONLY

- 1 FISSARE LE GAMBE AL TELAIO
fix the legs with the metal frame
- 2 FISSARE LE PIASTRE SOPRA LE GAMBE
(SOLO PER TAVOLI CON PIANI IN CRISTALLO)
fix the plates on the legs
(FOR TABLES WITH CRYSTAL TOP ONLY)



FASI / phases 3-4-5

- 3 SFONDARE LE PREFORATURE SOTTO IL TOP DEL MOBILE DI SERVIZIO
E FISSARE DA SOTTO (vedi SCHEMA X)
break through the pre drilling under the top of the service unit
and fix from below (please see scheme X)

- 4 ATTENZIONE! PRIMA DI FISSARE IL PIANO
METTERE IN BOLLIA TUTTA LA STRUTTURA!
Attention! Level the structure before fixing the desk tops!

- 5 POSIZIONARE IL PIANO E FISSARE DA SOTTO
ATTENZIONE! INDICAZIONI PARTICOLARI PER PIANI IN VETRO:
FISSAGGIO MANUALE DELLE VITI! (NON USARE L'AVVITATORE)
place the desk top and fix from below
attention! special indications for glass tops:
fix the screws manually! (do not use electric screwdriver)

CODE	D1 x D2	COLOUR	CODE	Ø x L	COLOUR	CODE	Ø x L	COLOUR	CODE	Ø x L	COLOUR
505190422	6 x 12	FERRO	506223000	6MA x 15	ZINCATA	506663809	6MA x 15	ZINCATO	506223005	6MA x 60	ZINCATA
	1/4" x 7/16" - iron			6MA x 9/16" - zinc plated			6MA x 9/16" - zinc plated			6MA x 2 3/8" - zinc plated	
		L x 1			M x 1			D x 4			G x 2
				TB/X			TP/E			TP/E	

