

FASI / phases 1-2-3

- 1** FISSARE LE GAMBE AL TELAIO
fix the legs with the metal frame
- 2** FISSARE LE PIASTRE SOPRA LE GAMBE
fix the plates on the legs
- 3** ATTENZIONE! PRIMA DI FISSARE IL PIANO
METTERE IN BOLLA TUTTA LA STRUTTURA!
Attention! Level the structure before fixing the desk tops!


CODE	Ø x L	COLOUR
506663710	10MA x 40	ZINCATA
10MA x 1 9/16" - zinc plated		
TCL/E	L	A
		x 4

CODE	COLOUR
505182205	FERRO
iron	
B	x 1

CODE	COLOUR
423716019	TITANB
C	x 4

CODE	Ø x L	COLOUR
506663809	6MA x 15	ZINCATO
6MA x 9/16" - zinc plated		
TP/E		D
		x 4

CODE	COLOUR
505182201	FERRO
iron	
E	x 1




FASI / phases 3-4-5-6

- 4** AGGANCIARE IL CANALE PORTA-CAVI
SULLE TRAVI
hook the cable tray on the beams
- 5** POSIZIONARE IL PIANO E FISSARE DA SOTTO
**ATTENZIONE! INDICAZIONI PARTICOLARI
PER PIANI IN VETRO:
FISSAGGIO MANUALE DELLE VITI!
(NON USARE L'AVVITATORE)**

place the desk top and fix from below
**attention! special indications for glass tops:
 fix the screws manually!
 (do not use electric screwdriver)**



- 6** INSERIRE IL TOP ACCESS
insert the top access


DETTAGLIO POSIZIONE CANALE PORTA-CAVI SU TRAVI
 detail of cable tray on beams


CODE	Ø x L	COLOUR
506663809	6MA x 15	ZINCATO
6MA x 9/16" - zinc plated		
TP/E		D
		x 4

CODE	COLOUR
505182201	FERRO
iron	
E	x 1

CODE	Ø x L	COLOUR
506223005	6MA x 60	ZINCATA
6MA x 2 3/8" - zinc plated		
TP/E	L	G
		x 12